



Helpful Hints & Information for your iPAQ PCD-1

- Due to widely varying characteristics, some CD-RW discs may not be compatible with your PCD-1.
- Use of 90+ minute CDs is not recommended.
- If a disc is not recognized (display reads “No Disc”), ensure that the disc is clean and free of scratches. If the problem persists, turn the player off, remove all power, re-insert the batteries, then restart.
- Your PCD-1 is shipped with Electronic Skip Protection (ESP) turned off. Place the unit in Stop mode prior to switching ESP on/off.
- Always turn off your PCD-1 before plugging in the AC adapter.

First Edition (September 2001)



261414-001